

Spa Bath Lighting Kit - From Byretech

Tools required to complete the installation.

- Hole cutter / drill
- Tape measure
- Sealant (supplied)
- Kitchen roll to wipe fingers
- PTFE tape

Consult Electrician on how
To wire this item Via RCD.



Part Numbers

1 x LED Kit BBL001
2 x LED Kit BL002

Installation instructions

• Make sure you have a power source under your bath that is RCD (residual current device for safety) connected so as the light transformer may be connected to this. If you don't have this, please consult a qualified electrician to advise you.

• Decide where you will mount the LED On/Off switch and the LED colour changing light on the bath, making sure you have enough cable to join the items to the transformer. Take care not to select a severely curved surface to mount the LED / Switch on as this will stress this component.

Note. Normally these are both mounted at the tap end of the bath. Make sure that the LED lamp is not directly facing you when sitting in the bath as it will be distracting when bathing (I.e mount lamp on the side of the bath). Mount the switch on the rim of the bath as it can not be mounted under the water.

• Select the appropriate circular hole cutter. **Care must be take to ensure a tight fit**, so take care not to cut the hole too large for both the LED and Switch. **Note 41mm dia hole for LED & 32mm dia hole for switch**

• Cut the holes and mount the switch and LED in place. You may need PTFE tape and the sealant to provide a watertight seal for the switch and the Lamp.

• With the power to the transformer OFF, connect the switch and LED lamp to the transformer wiring. White connector to white connector / black to black.

• Apply power **via an RCD** to the transformer and test the lights. The switch should illuminate and a single press changes the colours. From Off, hold down the switch gently for 2 seconds to rotate the colours (instructions in box).

• Fill bath with water past the LED lamp and check for leaks. Use more PTFE tape to seal if required behind nut under bath.

• Your installation is complete. See Byretech.com for install video.



Red Wire - Live
White Wire - Neutral



Byretech Ltd
The Bathroom Water Damage
Prevention specialists

Byretech Ltd
Unit 51 Padgets Lane, South Moons Moat,
Redditch, Worcestershire B98 0RD UK.
Phone: +44 (0) 1527 522 522 Fax: +44 (0) 1527 522 111
E-mail: info@byretech.com Web: www.byretech.com