Secura Grab Rail - Contents and Installation guide.

- Decide on location of grab rail and use masking tape to cover the area
- Unscrew cover plates on grab rail and slide them towards the grab rail
- · Draw around base plate with a pencil once in its desired position
- Using the Allen key provided remove base plates from grab rail
- Check the fixings supplied are adequate This is the installers responsibility (Byretech will not be held liable for poor installation practice or incorrect use of fitting / fixings)
- Mark hole locations and drill 8mm masonry drill bit to depth required
- Insert raw plugs and screw bases to wall
- Push on grab rail tighten Allen key screw back on cover plate
- Installation is now complete











