


# SHOWER RAIL

Available from  
[www.byretech.com](http://www.byretech.com)

## Eaves Rail Installation.

### Tools required to complete the installation.

- Electric Drill with 8mm masonry drill bit 
- Suitable Hex Screwdriver 
- Masking tape to ensure tiles are not damaged when drilling 
- Stainless Steel hacksaw blade 
- Spirit level to get rail level 
- Tape measure 



## Installation instructions

- Measure up from the **inside base of the bath approximately 190 cm** and make a horizontal line where you would like bracket "a" to be positioned

**(This is so the rail and new curtain fit perfectly as shower curtains are normally 180cm drop from shower rail)**

- Make the shower rail up without gluing and once complete you can decide on the length of the shower rail.
- Once you have carefully decided on the desired length of your shower rail use a stainless steel hacksaw blade to cut the stainless steel rail to your desired size.
- Clean the inside of the **non cut end** of the tube and also the elbow with with a **clean cloth**.

**Note - Take Care there may be sharp metal exposed at the ends.**

Take the metal glue provided and add a moderate amount to the inside of the 1m tube. Push the elbow into the tube and leave to set for 10 minutes.

- Re-assemble the Eaves Shower Rail and hold it up against the two walls as per Diagram 1 and mark the position of the point where the brackets touches the wall on your newly marked horizontal line with a pencil "a" and "b".

**Note. You will need an 8mm masonry drill bit to go through your tiles**

- Fix masking tape to the area where you will fix the brackets and carefully mark and drill the three holes, then repeat this on the sloping ceiling. Fit the raw plugs.
- Offer the rail up to the wall / sloping ceiling and fix into place. Now tighten up the retaining grub screws on the brackets. Give the rail a polish with furniture polish or similar and your rail is now completed.






Diagram 1.

- Tape up area with masking tape
- Mark & drill holes using an 8mm masonry drill
- Add rawplugs & fix bracket to tiled wall and sloped ceiling



- Ensure rod is level and straight
- Mark new bracket and repeat above procedure then fix rail in place



**Byretech Ltd**  
The Bathroom Water Damage Prevention specialists

Byretech Ltd  
Unit 51 Padgets Lane, South Moons Moat,  
Redditch, Worcestershire B98 0RD UK.  
Phone: +44 (0) 1527 522 522 Fax: +44 (0) 1527 522 111  
E-mail: [info@byretech.com](mailto:info@byretech.com) Web: [www.byretech.com](http://www.byretech.com)